

URC1 code setting for Dayens Menuetto & Ecstasy III

1. Three-digit code for your amplifier remote control is **563**.
2. Press and hold the SET button then press the AUX button.
3. Release all buttons as soon as the red LED located next to the SET button goes on.
4. Enter the mentioned three-digit code (563) within 10 seconds.
If the code is valid, the LED goes out.
If the code you entered is invalid (e.g. 777), the LED will stay on after two rapid flashes.
You can now re-enter the code.
5. If the three-digit code does not work, try with adding zero as the first of the four digit code: **0563**.
6. Direct the remote control toward the amplifier you have previously turned on, and try if the volume control works.
7. Enjoy!